

Disassembly Instructions


1. Ensure that there are no foreign objects or people inside the inflatable. **If there is water in or on the inflatable from rain, dry the inflatable first.** To dry the inflatable, inflate the unit with the blowers and leave inflated for at least half an hour.
2. If not done so already, turn the blowers off.

3. Unzip the deflation zippers to expedite the deflation.

4. Allow the inflatable to completely deflate.


5. Remove any stakes or sandbags attached to the inflatable

6. Fold the walls of the inflatable that droop over the base inwards so that the base is the edge.



7. Fold the walls of the inflatable into the center as in the diagram on top.

8. Roll the unit slowly from one end to another as in the diagram on the right. **Rolling it towards either the deflation zipper or blower inlet will make forcing the air out easier.**



9. Secure the rolled up inflatable with the fastening ties.